



Applicability: BMW

Cod. KRBEA-014 – INSTALLATION AND USE



1. Turn off the engine.



2. Locate and disconnect the 4 pin connectors of the o2 sensor. It is usually placed on the left side.
Follow the silicone sheath coming from the o2 sensor to find the connectors.
3. Connect the Rapid Bike connectors in-line with the stock ones.

4. Connect the 6 pin connector and the 2 pin connector to the RapidBike Easy module.



Settings

GREEN LED / LED VERDE



The green led shows the state of the device:

Led off = not powered.

Led on = powered, o2 sensor cold.

Led flashing = powered, o2 sensor hot, the device is working.

5. Set the trimmers as follows:

Trimmer 1 = SETTING

Trimmer 2 = FUEL RATIO

MAKE	MODEL	TRIMMER 1	TRIMMER 2
BMW	All models	6 for stock bikes 5 for bikes with aftermarket exhaust	+2
Husqvarna	All models	6 for stock bikes 5 for bikes with aftermarket exhaust	+2

- Turn on the ignition and verify that the green led is on.
- Turn on the engine and wait some minutes until the green led starts to flash.
- Fasten the cover with the screws.

Dimsport Srl

Zona Industriale Madonnina - Loc. San Iorio

15020 SERRALUNGA DI CREA (AL) - ITALY

T (+39) 0142.9552 F (+39) 0142.940094

www.dimsport.it

RapidBike

ASSISTENZA TECNICA – TECHNICAL SUPPORT

Tel. (+39) 0142.9552

E-mail: support.rapidbike@dimsport.it

UFFICIO COMMERCIALE – COMMERCIAL DEPT.

Tel. (+39) 0142.9552

E-mail: info.rapidbike@dimsport.it



a company of
una azienda del gruppo



www.rapidbike.it
